


© Solder Instruction

- 1. Cable should be prepared for soldering. The cable/wires must be pretinned.
- 2. Insert cable/wire into solder cup.
- 3. Operate the soldering iron at 350°C, 50 Watt max. and use a pencil tip.
- 4. Apply some solder to the solder tip of the soldering iron.
- 5. Put tip to wire in solder cup.
- 6. After 1 second bring in solder.
- 7. Heat for 3 seconds longer. Do not heat contact more than 4 seconds in total.
- 8. Remove soldering iron.
- 9. Wait until solder gets rigid again.
- 10. Do not solder adjacent contacts consecutively, alternate position within the connector to minimize heat build up.

RECOMMENDED PANEL CUT-OUT



	⊢	HOMP	<u>۽</u>				tol	erance		scale: 4:1
	NOT THOU	5 S	=							material: SEE SHEET 1
AY NOT BE COPIED OR INY WAY, AND MAY NOT A THIRD PARTY WITHOL			5						dim. in mm	
	₩ Σ ≻ '	3 5	2					date	name	title:
	AND PAR	D AWING	Ī				drawn	29.09.14	Lehmenkühler	RECOMMENDED PANEL CUT-OU
	MAY,						appd.	26.01.15	Fischer	D-SUB FEMALE 25pos. SOLDER CUP
	N A I		3				norm			with open 4-40 UNC thread
	₹ 5 5 5 6 5 6 5 6 5 6 5 6 5 6 6 6 6 6 6						d-old			dwg no: DIN
1 3 3	M H S H H	≟∣≥		C Ä5827	25.09.15	Unkrüer	_	45 =		15K1A1544
	DRA ODU ASSE TEN	WINEKSH	ā a	Original				? 2 1		15K1A1544
	HIS EPR			. description	date	name	•			part no: SFF SHFFT 1