



## **AP8803EV1 EVALUATION BOARD USER GUIDE**

#### DESCRIPTION

The AP8803EV1, Figure 1, is a double sided evaluation board for the AP8803 LED driver with internal switch. The evaluation board is preset to drive 680mA into a single LED, or multiple LEDs, the maximum number of which depends on their total forward voltage drop.

The operating voltage is nominally 30 volts, but it can be reduced to a minimum of 8 volts. The 68uH inductor used in the circuit is based on this nominal supply, which should be connected across the +Vin and Gnd pins. **Note: The evaluation board does not have reverse battery protection.** The nominal current, 680mA, is set with the 0R15 sense resistor, R1.

Terminal CTRL provides a connection point for DC or PWM dimming and shutdown.

Warning: At 30V nominal operation with 680mA output, the LED will be hot and very bright




Figure 1: AP8803EV1 evaluation board

#### **AP8803 DEVICE DESCRIPTION**


The AP8803 is a continuous mode inductive driver in a TSOT23-5 package, for driving one or more series-connected LEDs efficiently from a voltage source higher than the LED voltage. The device includes the output switch and a current sense circuit, which requires an external sense resistor to set the nominal current up to 1000mA.

### **AP8803 DEVICE FEATURES**

- Drives one or more series-connected LEDs
- LEDs up to 1000mA.
- Internal 30V switch.
- Wide input voltage: 8V to 30V.
- Inherent open circuit LED protection.
- Brightness control using DC or PWM.
- Internal PWM filter.

### **DEVICE APPLICATIONS**

- LED flashlights.
- High Power LED driving.
- Low-voltage halogen replacement LEDs.
- Automotive lighting.
- Illuminated signs.



### TSOT23-5 pack

AP8803 Device Pin Definition					
Name	Pin No	Description			
SW	1	Drain of NDMOS switch.			
GND	2	Ground (0V).			
CTRL	3	Internal voltage ref. pin (1.25V):			
		<ul> <li>Leave floating for normal operation.</li> </ul>			
		<ul> <li>Connect to GND to turn off output current.</li> </ul>			
		<ul> <li>Drive with DC voltage (0.3V to 1.25V) or with PWM signal to</li> </ul>			
		Adjust output current or			
		<ul> <li>Connect a capacitor from this pin to ground to set soft-start</li> </ul>			
		time.			
SET	4	Connect a sense resistor, Rs, from the CTRL pin to VIN to sense the			
		nominal output current. Nominal I <sub>out</sub> = 0.1/ R1			
VIN	5	Input voltage: 8V to 30V. Decouple to ground with a 4.7uF or higher			
		ceramic capacitor.			

### **ORDERING INFORMATION**

EVALBOARD ORDER NUMBER
AP8803EV1

DEVICE ORDER NUMBER			
AP8803E5TA			

Please note: Evaluation boards are subject to availability and qualified sales leads.

# AP8803EV1 EVALUATION BOARD REFERENCE DESIGN

The AP8803EV1 is configured to the reference design in Figure 2.

The operating voltage is a nominal 30V. The nominal current is set at 680mA with a 0R15 sense resistor, R1 and the circuit operates in continuous mode at approximately 180kHz, with a 68uH inductor and a single LED.

An accurate way of determining the current is to measure the voltage on the sense resistor. A 10K resistor and a 1uF capacitor can be used to form a low pass filter, the voltage across the capacitor representing a more stable DC reading of current . 100mV represents 1 Amp when using a 0R1 sense resistor.

The CTRL pin has a low pass filter within the AP8803 chip to provide some decoupling and a soft start, but the external capacitor C1 (100nF) is used to provide additional decoupling to reduce any high frequency noise, as well as providing an extra amount of soft start.

Both DC and PWM dimming can be achieved by driving the CTRL pin. For DC dimming, the CTRL pin may be driven between 0.3V and 1.25V. Driving the CTRL pin below 0.2V will shutdown the output current. For PWM dimming, an external open-collector NPN transistor or open-drain N-channel MOSFET can be used to drive the CTRL pin. The PWM frequency can be low, around 100Hz to 1kHz, or high, between 10kHz to 50kHz.

For low frequency PWM, C1 should be removed from the evaluation board, to give a more accurate duty cycle .

Shorting R2 will connect the test pin CTRL to device pin CTRL, if required.

The soft-start time will be nominally 0.5ms without capacitor C1. Adding C1 will increase the soft start time by approximately 0.5ms/nF

For other reference designs or further applications information, please refer to the AP8803 datasheet.

### **Schematic Diagram**




Figure 2: Schematic of the Evaluation Board

#### **AP8803 Operation**

In normal operation, when voltage is applied at +Vin, the AP8803 internal NDMOS switch is turned on. Current starts to flow through sense resistor R1, inductor L1, and the LED. The current ramps up linearly, and the ramp rate is determined by the input voltage +Vin and the inductor L1. This rising current produces a voltage ramp across R1. The internal circuit of the AP8803 senses the voltage across R1 and applies a proportional voltage to the input of the internal comparator. When this voltage reaches an internally set upper threshold, the NDMOS switch is turned off. The inductor current continues to flow through R1, L1, the LED and the schottky diode D1, and back to the supply rail, but it decays, with the rate of decay determined by the forward voltage drop of the LEDs and the schottky diode. This decaying current produces a falling voltage at R1, which is sensed by the AP8803. A voltage proportional to the sense voltage across R1 is applied at the input of the internal comparator. When this voltage falls to the internally set lower threshold, the NDMOS switch is turned on again. This switch-on-and-off cycle continues to provide the average LED current set by the sense resistor R1. Please refer to the datasheets for the threshold limits, AP8803 internal circuits, electrical characteristics and parameters.

#### **AP8803EV1 Component list**

Ref	Value	Package	Part Number	Manufactu	Notes
				rer	
U1	AP8803	TSOT23-	AP8803E5TA	Diodes	DC-DC converter
		5		Zetex	
D1	40V, 3A		B340B	Diodes	Schottky diode
				Zetex	-
R1	0R15	0805		Generic	5%
R2,	1K	0805		Generic	1%
C1	4.7uF 50V	1210		Generic	X7R
			C1210X475K5RAC	KEMET	
C2, C3	100nF, 100V	0805		Generic	X7R
			NMC0805X7R104K100 PF	NIC Comps	
			GRM21BR71H104KA01L	MURATA	
C4	100nF 100V	1206		Generic	X7R
			NMC1206X7R104K100	NIC Comps	
L1	68uH		MSS1038-683ML	Coilcraft	
			NPIS24H680MTRF	NIC Comps	

Note: The component part numbers are correct at the time of publication. Diodes Inc reserves the right to substitute other parts where necessary, without further notification.




Figure 3: Component layout

AP8803EV1 Connection Point Definition			
Name	Description		
Vin	Positive supply voltage.		
Gnd	Supply Ground (0V).		
CTRL	Internal voltage ref. pin (1.25). This pin can be used to achieve dimming and soft-start, and for switching the output current off.  • Leave floating for normal operation.  • See 'Other Features' section to achieve dimming, and soft-start and for switching the output current off.		
LED A	LED A connects to the external LED anode		
LED K	LED K connects to the external LED cathode		

## AP8803EV1 Basic operation at full voltage

- 1. Connect Vin and Gnd Warning: The board does not feature reverse battery/supply protection.
- 2. Set the PSU to 30V
- 3. Turn on the PSU and the LED will illuminate and the current should be approximately 680mA. Warning: Do not stare at the LED directly.

# Circuit features (Remove power whilst changing components!) Soft-start

1. Fit a capacitor at C2 to alter the rise-time of the CTRL pin at start-up. The output impedance is 200k so

200,000R x C2 (farads) is the time constant to reach 66% of the maximum output current

### Switching the output current off

1. Shorting the CTRL pin to Gnd will cause the LED current to go to zero. Releasing this pin will create a soft-start power-up sequence.

### Changing the LED current

- 1. Remove R1.
- 2. Calculate and fit a new sense resistor, R1, the value of which is based on the required LED current without dimming. R1 can be calculated using following equation:

R1 =  $0.1 \text{V/I}_{\text{OUT}}$  where  $I_{\text{OUT}}$  = the LED current. R1 = the sense resistor value in ohms. 0.1V is the nominal sense voltage with 'CTRL' open circuit or set to 1.25V.

#### **PERFORMANCE**

The system efficiency depends on the sense resistor, supply voltage, switching inductor and the number of LEDs.

With a 30V supply, the switching frequency is typically 200kHz, and the efficiency level is >85%.

INTENTIONALLY BLANK

#### **IMPORTANT NOTICE**

DIODES INCORPORATED MAKES NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS DOCUMENT, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE (AND THEIR EQUIVALENTS UNDER THE LAWS OF ANY JURISDICTION).

Diodes Incorporated and its subsidiaries reserve the right to make modifications, enhancements, improvements, corrections or other changes without further notice to this document and any product described herein. Diodes Incorporated does not assume any liability arising out of the application or use of this document or any product described herein; neither does Diodes Incorporated convey any license under its patent or trademark rights, nor the rights of others. Any Customer or user of this document or products described herein in such applications shall assume all risks of such use and will agree to hold Diodes Incorporated and all the companies whose products are represented on Diodes Incorporated website, harmless against all damages.

Diodes Incorporated does not warrant or accept any liability whatsoever in respect of any products purchased through unauthorized sales channels. Should Customers purchase or use Diodes Incorporated products for any unintended or unauthorized application, Customers shall indemnify and hold Diodes Incorporated and its representatives harmless against all claims, damages, expenses, and attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized application.

Products described herein may be covered by one or more United States, international or foreign patents pending. Product names and markings noted herein may also be covered by one or more United States, international or foreign trademarks.

#### LIFE SUPPORT

Diodes Incorporated products are specifically not authorized for use as critical components in life support devices or systems without the express written approval of the Chief Executive Officer of Diodes Incorporated. As used herein:

- A. Life support devices or systems are devices or systems which:
  - 1. are intended to implant into the body, or
  - 2. support or sustain life and whose failure to perform when properly used in accordance with instructions for use provided in the labeling can be reasonably expected to result in significant injury to the user.
- B. A critical component is any component in a life support device or system whose failure to perform can be reasonably be expected to cause the failure of the life support device or to affect its safety or effectiveness.

Customers represent that they have all necessary expertise in the safety and regulatory ramifications of their life support devices or systems, and acknowledge and agree that they are solely responsible for all legal, regulatory and safety-related requirements concerning their products and any use of Diodes Incorporated products in such safety-critical, life support devices or systems, notwithstanding any devices- or systems-related information or support that may be provided by Diodes Incorporated. Further, Customers must fully indemnify Diodes Incorporated and its representatives against any damages arising out of the use of Diodes Incorporated products in such safety-critical, life support devices or systems.

Copyright © 2009, Diodes Incorporated

www.diodes.com

### Sales offices

The Americas 3050 E. Hillcrest Drive Westlake Village, CA 91362-3154 Tel: (+1) 805 446 4800 Germany Fax: (+1) 805 446 4850 Tel: (+49) 894 549 490

Europe Kustermannpark Balanstraße 59, D-81541 München Fax: (+49) 894 549 4949 Taiwan 7F. No. 50. Min Chuan Road Hsin-Tien Taipei, Taiwan Tel: (+886) 289 146 000 Fax: (+886) 289 146 639

Shanqhai Rm. 606. No.1158 Changning Road Shanghai, China Tel: (+86) 215 241 4882 Futian CBD, Fax (+86) 215 241 4891 Shenzhen, China

Shenzhen Room A1103-04 ANLIAN Plaza, #4018 Jintian Road Tel: (+86) 755 882 849 88 Fax: (+82) 312 731 885 Fax: (+86) 755 882 849 99

Korea 6 Floor, Changhwa B/D, 1005-5 Yeongtong-dong, Yeongtong-gu, Suwon-si, Gveonggi-do, Korea 443-813 Tel: (+82) 312 731 884